


FIG. 7 SERIES 7000 TRANSMISSION — EXPLODED VIEW





INPUT SHAFT

M802011  
M802048

HM89412

G2

DX

D1

THM7

THM78

THRUST WASHERS TO THE WHEEL WASHER (BL) IS LOCATED DIRECTLY AGAINST GROUND FACE C CLUTCH HUB GEAR (RED) STEEL THRUST WASHER (GREEN) SHOULD BE LOCATED AGAINST BEARING FACE (BROWN)